

Operating System	Storage	Server(s)	Host Bus Adapters	Interconnect FC Switches	Multi-Path Software	Other
Windows Server 2008 x64 Enterprise Edition	Hitachi TagmaStore Adaptable Modular Storage - Model 1000, 500, 200 Hitachi TagmaStore Workgroup Modular Storage - Model 100 Microcode Version: 0775	Max supported nodes = 2 Hewlett Packard ProLiant - DL585, DL580G5	QLogic - QLA2462 Driver: 9.1.4.5 BIOS: 1.04 FW: 4.00.27	McData 4700, 400 Firmware version: 9.02	Hitachi Dynamic Link Manager (HDLM) Version: 5.9	
Windows Server 2003 x86 Enterprise Edition	Hitachi TagmaStore Adaptable Modular Storage - Model 1000, 500, 200 Hitachi TagmaStore Workgroup Modular Storage - Model 100 Microcode Version: 0773	Max supported nodes = 8 Hewlett Packard ProLiant - DL360G4, DL380G4 - DL380G5, DL385 - DL585, DL580G2 - DL580G3, DL760G2	QLogic - QLA2340 - QLA2342 Driver: 9.1.4.15 BIOS: 1.52 FW: 3.03.21	Brocade SilkWorm 3850, 3900, 4100 4900, 12000, 48000 Firmware version: 5.3.0b Brocade SilkWorm 3800 Firmware version: 3.2.1b	Hitachi Dynamic Link Manager (HDLM) Version: 5.9	
Windows Server 2003 x86 Enterprise Edition	Hitachi TagmaStore Adaptable Modular Storage - Model 1000, 500, 200 Hitachi TagmaStore Workgroup Modular Storage - Model 100 Microcode Version: 0773	Max supported nodes = 8 Hewlett Packard ProLiant - DL360G4, DL360G5 - DL385G2, DL380G5 - DL585G2, DL380G4(x2) - DL580G3	QLogic - QLe2462 Driver: 9.1.4.15 BIOS: 1.16 FW: 4.00.26	Brocade SilkWorm 3850, 3900, 4100 4900, 12000, 24000 48000 Firmware version: 5.3.0b Brocade SilkWorm 3800 Firmware version: 3.2.1b	Hitachi Dynamic Link Manager (HDLM) Version: 5.9	

<p>Windows Server 2003 x86 Enterprise Edition</p>	<p>Hitachi TagmaStore Adaptable Modular Storage - Model 1000, 500, 200</p> <p>Hitachi TagmaStore Workgroup Modular Storage - Model 100</p> <p>Microcode Version: 0760</p>	<p>Max supported nodes = 8</p> <p>Hewlett Packard ProLiant</p> <p>- DL140G3, DL360G4 - DL360G5, DL380G4 - DL380G5, DL385G2 - DL580G3, DL585G2</p>	<p>QLogic - QLA2340 - QLA2342</p> <p>Driver: 9.1.2.16 BIOS: 1.47 FW: 3.03.19</p>	<p>Brocade SilkWorm 4100, 4120, 4140 4900, 48000, 3900 Firmware version: 5.1.0d</p> <p>Brocade SilkWorm 3800 Firmware version: 3.2.1b</p>	<p>Hitachi Dynamic Link Manager (HDLM)</p> <p>Version: 5.8</p>	
<p>Windows Server 2003 x86 Enterprise Edition</p>	<p>Hitachi TagmaStore Adaptable Modular Storage - Model 1000, 500, 200</p> <p>Hitachi TagmaStore Workgroup Modular Storage - Model 100</p> <p>Microcode Version: 0760</p>	<p>Max supported nodes = 8</p> <p>Hewlett Packard ProLiant</p> <p>- DL140G3, DL360G4 - DL360G5, DL380G4 - DL380G5, DL385G2 - DL580G3, DL585G2</p>	<p>QLogic - QLe2462</p> <p>Driver: 9.1.2.16 BIOS: 1.24 FW: 4.00.18</p>	<p>Brocade SilkWorm 4100, 4120, 4140 4900, 48000, 3900 Firmware version: 5.1.0d</p> <p>Brocade SilkWorm 3800 Firmware version: 3.2.1b</p>	<p>Hitachi Dynamic Link Manager (HDLM)</p> <p>Version: 5.8</p>	
<p>Windows Server 2003 x86 Enterprise Edition</p>	<p>Hitachi TagmaStore Adaptable Modular Storage - Model 1000, 500, 200</p> <p>Hitachi TagmaStore Workgroup Modular Storage - Model 100</p> <p>Microcode Version: 0720</p>	<p>Max supported nodes = 8</p> <p>Hewlett Packard ProLiant</p> <p>- DL380G3, DL380G4 - DL560, DL760G2 - DL580G2, DL580G3 - ML530G2, ML370G3</p>	<p>QLogic - QLA2340 - QLA2342</p> <p>Driver: 9.0.1.12 BIOS: 1.45 FW: 3.03.06</p>	<p>Brocade SilkWorm 3250, 3850, 3900, 12000, 24000 Firmware version: 4.4.0e</p> <p>Brocade SilkWorm 2800 Firmware version: 2.6.2a</p>	<p>Hitachi Dynamic Link Manager (HDLM)</p> <p>Version: 5.6</p>	

***Note:** Servers can be used homogeneously or heterogeneously within a cluster